Sun Netra CP3x40 Switch Administration and Maintenance

Student Guide - Volume 1

EC-170-SOL CP3x40 (Rev A)

D63733GC10
Edition 1.0
D64501

ORACLE

Copyright © 2009, 2010, Oracle and/or its affiliates. All rights reserved.

Disclaimer

This document contains proprietary information, is provided under a license agreement containing restrictions on use and disclosure, and is protected by copyright and other intellectual property laws. You may copy and print this document solely for your own use in an Oracle training course. The document may not be modified or altered in any way. Except as expressly permitted in your license agreement or allowed by law, you may not use, share, download, upload, copy, print, display, perform, reproduce, publish, license, post, transmit, or distribute this document in whole or in part without the express authorization of Oracle.

The information contained in this document is subject to change without notice. If you find any problems in the document, please report them in writing to: Oracle University, 500 Oracle Parkway, Redwood Shores, California 94065 USA. This document is not warranted to be error-free.

Sun Microsystems, Inc. Disclaimer

This training manual may include references to materials, offerings, or products that were previously offered by Sun Microsystems, Inc. Certain materials, offerings, services, or products may no longer be offered or provided.Oracle and its affiliates cannot be held responsible for any such references should they appear in the text provided.

Restricted Rights Notice

If this documentation is delivered to the U.S. Government or anyone using the documentation on behalf of the U.S. Government, the following notice is applicable:

U.S. GOVERNMENT RIGHTS
The U.S. Government’s rights to use, modify, reproduce, release, perform, display, or disclose these training materials are restricted by the terms of the applicable Oracle license agreement and/or the applicable U.S. Government contract.

Trademark Notice

Oracle and Java are registered trademarks of Oracle and/or its affiliates. Other names may be trademarks of their respective owners.

AMD, Opteron, the AMD logo, and the AMD Opteron logo are trademarks or registered trademarks of Advanced Micro Devices. Intel and Intel Xeon are trademarks or registered trademarks of Intel Corporation. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. UNIX is a registered trademark licensed through X/Open Company, Ltd.

This page intentionally left blank.

This page intentionally left blank.

Table of Contents

Course Goals ..... Preface-i
How Prepared Are You? ..... Preface-ii
Introductions ..... Preface-iii
How to Use Course Materials ..... Preface-iv
Conventions ..... Preface-v
    Typographical Conventions ..... Preface-vii
    Additional Conventions ..... Preface-viii
Objectives 1-1
Additional Resources 1-2
Introduction To The Sun NetraTM CT900 Server 1-3
Network Provider Computing Requirements 1-4
    Central Office (CO) Requirements 1-4
    ETSI 1-5
    CP-TA Standards 1-5
The Netra Servers 1-6
    Introducing NEBS Requirements 1-6
    Reviewing the Purpose of NEBS Requirements 1-7
    Reviewing NEBS Levels 1-7
    Using NEBS Criteria in Business Applications 1-8
    Planning a Reliable Environment 1-9
    Sun Servers And Sun Netra Servers 1-9
What is ATCA? 1-10
    ATCA 3.x 1-10
    ATCA Benefits 1-11
    MicroTCA 1-12
    The PICMG 1-12
Common Applications for ATCA 1-13
    Application Hosting 1-13
    Routing and Network Traffic Management 1-13
The Sun CT900 ATCA Blade Server 1-14
    CT900 ATCA Hardware Components 1-15
    CT900 Node Blades 1-15
    Advanced Mezzanine Cards 1-17

Copyright 2009 Sun Microsystems, Inc. All Rights Reserved. Sun Services, Revision A

Objectives 2-1
Additional Resources 2-2
The CT900 Shelf 2-3
The Shelf Midplane 2-6
The CT900 Midplane 2-6
The Shelf Networks 2-8
Network Names 2-8
The Base Networks 2-8
The Extended Networks 2-9
The Management Network 2-10
The Dual Star Network Topology 2-11
Individual Board Network Connectivity 2-12
Network Connectivity Examples 2-14
Internal Product Names 2-16
Firmware Types and Locations 2-17
CT900 Input Power 2-19
Input Power Zones 2-20
AC Power Support 2-21
The Shelf Power Budget 2-22
Shelf Cooling 2-24
Air Filter Replacement 2-25
CT900 Rack Mounting 2-26
Rack Airflow with the CT900 2-27
PEM and Fan LEDs and Hot Swap Indicators 2-28
Shelf Upgrades for 10 Gb-Capable Boards 2-30
Enhanced Cooling Shelf 2-30
Upgraded Fan Trays 2-31
Objectives 3-1
Additional Resources 3-2
ShMM Function and Structure 3-3
The ShMM-500+ CPU Card 3-4
The Shelf Alarm Panel (SAP) 3-5
Alarm Levels 3-7
Resetting Alarms 3-8
ShMM Access and Login 3-9
Resetting a Lost Root Password 3-10
ShMM Boot Environment Variables 3-11
Default U-Boot Environment Variable Values 3-13
Changing Variables from the U-Boot Executive 3-14
Displaying the U-Boot and Environment Variables from Linux 3-15
Setting U-Boot Variables from the OS Command Line 3-17
Running ShMM Commands 3-18
Command Modes 3-18
Command Help 3-19
ShMM Firmware Information 3-19

Copyright 2009 Sun Microsystems, Inc. All Rights Reserved. Sun Services, Revision A

ShMM Status 3-20
The ShMM Front Panel 3-21
ShMM Network Interfaces and Connectivity 3-23
Network Configuration Information 3-24
Configuring Ethernet Interface Zero (`eth0`) 3-25
Ethernet Interface One (`eth1`) 3-27
Status Network Interfaces 3-27
ShMM Basic Network Configuration Options 3-29
One Floating ShMM RMCP Address 3-29
Two Floating ShMM RMCP Addresses 3-29
Two Floating ShMM IP Addresses Plus RMCP Address(es) 3-30
Persistent ShMM IP Addresses 3-30
Displaying RMCP Address Information 3-32
Configuring the RMCP Address 3-34
OpenHPI IPMI Direct Plug-in Configuration 3-35
ShMM Cross-Connect 3-37
Configuring the Cross-Connect Interface 3-37
CP3140 Cross-Connect Jumper 3-38
Configuring the ShMM to Use a Time Server 3-38
Booting the ShMM 3-40
Stopping the Shelf Manager Application 3-43
ShMM Failover 3-44
Identifying the Active ShMM 3-44
Forcing a ShMM Failover 3-44
Consequences of Failover 3-45
Network Switch Connectivity and Failover 3-45
Refreshing the ShMM OS Image 3-46
ShMM Firmware Upgrades 3-48
Preparing for the Firmware Upgrade 3-48
The `rupgrade_tool` Script 3-49
Upgrading the ShMM Firmware - R3U2 3-50
Upgrading the ShMM Firmware 3-50
The Firmware Upgrade Log 3-55
Upgrading the Midplane FRU PROM 3-57
Loading the ShMM Firmware From the U-Boot Prompt 3-62
The ShMM Logs 3-63
The ShMM Syslog 3-63
The SEL Log and `sel` Command 3-64
Configuring the SEL Log 3-67
The CLI Action Log 3-68
Gathering Support Information 3-70
Objectives 4-1
Additional Resources 4-2
ShMM Architecture 4-3
IPMI and I2C Buses 4-5
The I2C Bus 4-6

Copyright 2009 Sun Microsystems, Inc. All Rights Reserved. Sun Services, Revision A

IPMB Board Addresses 4-7
Board IPMC Firmware Level 4-9
Board Reset 4-9
Available Shelfman (`clia`) Commands 4-10
Shelf FRU Information 4-13
The `fru` Command 4-13
FRU IDs 4-15
Entity IDs 4-16
The `fruinfo` Command 4-18
E-Keying 4-22
Board Interface E-Keying 4-23
Board Link Designator 4-26
Switch Link E-Keying Information 4-27
Board Link Description Information 4-28
Board Link Activation Matching Rule and Example 4-28
Disabling Board E-Keying 4-30
Re-Enabling E-Keying 4-30
SAP User Alarm and System FRU LEDs 4-31
Reading the LEDs 4-31
Setting the LEDs 4-33
Fan Control and Cooling Commands 4-36
ShMM Response to Temperature Events 4-38
NEBS Fan Configuration 4-39
ShMM Power Status Commands 4-40
Available Shelf Power 4-40
Shelf Power Limits 4-44
Managing Component Hot Swapping 4-48
Making a Hot Swap Request from the ShMM 4-48
Checking Component Hot Swap Status 4-48
Enabling Automatic Hot Swapping 4-49
Disabling Automatic Hot Swapping 4-50
ShMM Handle Hot Swap Request 4-51
Board and Component Hot Swap States 4-52
Hot Swap Logging 4-53
ShMM SNMP Support 4-55
Available Information – Standard MIB 4-55
Available Information – OpenHPI MIB 4-57
Configuring SNMP on the ShMM 4-59
SNMPv2 Access 4-60
SNMPv3 Access 4-60
Accessing SNMP Data 4-62
Retrieving CT900 SNMP Data Using the ShMM MIBs 4-62
OpenHPI Subagent Configuration 4-63
Retrieving CT900 SNMP Data Using the OpenHPI MIBs 4-63
Specifying SNMP Trap Hosts 4-65
Specifying Trap Hosts 4-65

Copyright 2009 Sun Microsystems, Inc. All Rights Reserved. Sun Services, Revision A

Duplicate Traps 4-65
Available OpenHPI Notifications 4-66
The `autofwupgrade` Utility 4-67
`autofwupgrade` Command Syntax 4-68
Listing Current Firmware Levels 4-69
Determining the Available Upgrades 4-71
Performing the Upgrade 4-73
Net Console 4-77
Net Console Support 4-79
Net Console Escape Character 4-79
CP3060 and CP3260 Note 4-79
The ShMM GUI 4-80
Objectives 5-1
Additional Resources 5-2
Hardware Detail 5-4
Front Panel LEDs 5-9
The CP3020 RTM 5-12
RTM Power Requirements 5-14
CP3020 Blade Solaris Device Tree 5-15
`prtdiag` Output 5-15
`prtconf` Output 5-15
`prtpicl` Output 5-17
`eeprom` Output 5-18
CP3020 Blade Linux PCI Device Tree 5-19
CP3020 Operating Systems 5-21
Solaris on the CP3020 5-21
Linux on the CP3020 5-21
Network Configuration 5-23
Ethernet Interfaces 5-23
Board State 5-24
Booting 5-25
BIOS and Solaris GRUB Startup 5-25
Booting Solaris 10 5-28
Booting Linux 5-28
Firmware Upgrades Using the Bootball 5-31
CP3020 Firmware Upgrades from Solaris 5-34
Preparing for the Update 5-34
Updating the BIOS 5-34
Updating the BGE Firmware 5-36
Updating the IPMC Firmware 5-37
CP3020 Firmware Upgrades from Linux 5-40
Updating the BIOS 5-40
Updating the BGE Firmware 5-42
Updating the IPMC Firmware 5-43
Logs 5-45
..... 5-46

Copyright 2009 Sun Microsystems, Inc. All Rights Reserved. Sun Services, Revision A

Objectives 6-1
Additional Resources 6-2
CP3060 Hardware Characteristics 6-3
Hardware Detail 6-4
Front Panel LEDs 6-8
The CP3060 RTM 6-10
RTM Power Requirements 6-12
Solaris on the CP3060 6-13
Solaris Patches 6-13
Mandatory `/etc/system` Parameter 6-14
Using Compact Flash 6-14
CP3060 Blade Device Tree 6-16
`prtdiag` Output 6-16
`prtconf` Output 6-18
`prtpicl` Output 6-20
`eeprom` Output 6-22
Model Identification 6-25
ShMM Board State 6-25
Network Configuration 6-27
Ethernet Interfaces 6-27
The `e1000g` Driver Configuration File 6-28
Booting 6-31
Note on the CP3060 ALOM 6-31
CP3060 Firmware Upgrades 6-33
Displaying CP3060 Firmware Levels 6-33
System Firmware 6-33
Using `autofwupgrade` 6-35
Manual CP3060 Firmware Upgrades 6-38
The ShMM `flashupdate` Command 6-38
Manual IPMC Firmware Upgrade 6-39
..... 6-43
Objectives 7-1
Additional Resources 7-2
CP3220 Hardware Characteristics 7-3
Hardware Detail 7-4
Front Panel LEDs 7-9
Installation Requirements 7-10
Network Interfaces 7-11
Ethernet Interfaces 7-11
10 Gb Speed Support on Solaris 7-12
Board State 7-12
The CP32X0 Advanced RTMs 7-14
RTM Power Requirements 7-15
CP3220 Operating Systems 7-16
Solaris on the CP3220 7-16
Linux on the CP3220 7-16

Copyright 2009 Sun Microsystems, Inc. All Rights Reserved. Sun Services, Revision A

CP3220 Solaris Device Tree 7-18
prtdiag Output 7-18
prtconf Output 7-19
prtpicl Output 7-20
eeprom Output 7-21
Booting 7-22
BIOS and GRUB Startup 7-22
Booting Solaris 10 7-23
Booting Linux 7-23
CP3220 Firmware Upgrades 7-31
Manual Upgrades 7-31
Logs 7-34
Objectives 8-1
Additional Resources 8-2
CP3250 Hardware Characteristics 8-3
Hardware Detail 8-4
Intel L5408 CPU Features 8-7
Memory Installation 8-7
CP3250 Front Panel 8-8
Front Panel LEDs 8-9
Installation Requirements 8-10
The CP3250 AMC Slot 8-11
Network Interfaces 8-12
Ethernet Interfaces 8-13
10 Gb Speed Support on Solaris 8-14
RTM Power Requirements 8-17
CP3250 Operating Systems 8-18
Solaris on the CP3250 8-18
Linux on the CP3250 8-18
CP3250 Solaris Device Tree 8-20
prtdiag Output 8-20
prtconf Output 8-21
prtpicl Output 8-22
eeprom Output 8-24
Booting 8-25
BIOS and GRUB Startup 8-25
Booting Solaris 10 8-26
Booting Linux 8-27
CP3250 Firmware Upgrades 8-34
Manual Upgrades 8-34
Logs 8-37
Objectives 9-1
Additional Resources 9-2
CP3260 Hardware Characteristics 9-3
Hardware Detail 9-4
Front Panel LEDs 9-7

Copyright 2009 Sun Microsystems, Inc. All Rights Reserved. Sun Services, Revision A

Installation Requirements 9-7
The CP3260 I/O Architecture 9-8
The CP32X0 Advanced RTMs 9-9
RTM Power Requirements 9-10
Solaris on the CP3260 9-11
Solaris Patches 9-11
Using Compact Flash 9-11
Using USB Devices 9-12
CP3260 Blade Device Tree 9-14
`prtdiag` Output 9-14
`prtconf` Output 9-16
`prtpicl` Output 9-18
`eeprom` Output 9-22
Model Identification 9-25
ShMM Board State 9-25
CP3260 Network Configuration 9-27
Ethernet Interfaces 9-27
The `e1000g` Driver Configuration File 9-28
The `nxge` Driver Configuration File 9-30
`nxge` Interface Operating Data Rate 9-35
Booting the CP3260 9-38
Note on the CP3260 ILOM 9-38
CP3260 Firmware Upgrades 9-39
Determining the Current Firmware Level 9-39
System Firmware 9-39
Using `autofwupgrade` 9-40
Logs 9-44
Objectives 10-1
Additional Resources 10-2
The Advanced RTMs 10-3
ARTM Product Identifiers 10-4
ARTM Interface 10-4
ARTM Power Requirements 10-5
The Dual SAS Storage ARTM 10-6
CP3260 Solaris Device Paths 10-11
SAS Disk and Controller Connectivity 10-12
SAS Disk Controller Management 10-13
Configuring RAID Devices 10-13
From the OS 10-14
From the OBP 10-14
The 10 Gb Ethernet ARTM 10-16
The Dual 4 Gb Fibre Channel and Ethernet ARTM 10-21
Fibre Channel ARTM Device Locations and Connectivity 10-25
Fibre Channel Ports 10-25
Network Ports 10-26
ShMM Visibility 10-28

Copyright 2009 Sun Microsystems, Inc. All Rights Reserved. Sun Services, Revision A

Dual 4 Gb FC ARTM Carrier Board Expansion 10-30
ARTM MMC Firmware Updates 10-31
Using `autofwupgrade` From the ShMM 10-31
Upgrading MMC Firmware from the Host..... 10-35
Displaying the Current MMC Firmware Version from the Host..... 10-36
Upgrading the MMC Firmware from the Host..... 10-37
Objectives 11-1
Additional Resources..... 11-2
The Advanced Mezzanine Card (AMC)..... 11-3
Available AMC Functionality 11-3
AMC Carrier Boards..... 11-5
The AMC Card Types..... 11-6
AMC.0 – Base Specification 11-6
AMC.1 – PCI Express 11-7
AMC.2 – Ethernet..... 11-7
AMC.3 – Storage Attachment 11-8
AMC.4 – Rapid IO..... 11-8
AMC Ports and Channels 11-9
AMC Board-Module Connections..... 11-10
AMC Clock Interfaces..... 11-11
AMC and PMC Configuration and Restrictions..... 11-12
AMC Presence 11-12
The Sun StorageTek ATCA 4Gb FC Dual Port HBA AMC..... 11-13
Front Panel and LEDs..... 11-14
Device Tree Locations..... 11-16
Device Information..... 11-16
Firmware Updates..... 11-17
PCI-X and PCI Express 11-19
PCI and PCI-X Bus and Card Characteristics 11-20
PCI and PCI-X Bus Bandwidth 11-20
PCI Express Bus and Card Characteristics..... 11-21
PCI Express Bus Bandwidth..... 11-21
The PCI Bus Device Identification..... 11-23
Identifying a PCI Bus Device 11-23
PCI Device Driver to Device ID Matching 11-25
Objectives 12-1
Additional Resources..... 12-2
Carrier Grade OS Requirements..... 12-3
Platform Availability Software..... 12-3
Enhancements..... 12-3
Essential services and APIs 12-3
Security Features..... 12-5
OS Services and APIs for HA Middleware and Applications... 12-5
Serviceability Features..... 12-6
Scalability and Performance Features..... 12-8

Copyright 2009 Sun Microsystems, Inc. All Rights Reserved. Sun Services, Revision A

Standards Compliance 12-10
Development, debug, and optimization tools 12-10
Tools Description 12-10
Solaris 10 12-12
CP3060 and CP3260 Logical Domains 12-13
Operation 12-14
Carrier Grade Linux 12-15
CG Linux Requirements 12-15
Open HPI 12-17
CT900 OpenHPI Support 12-18
OpenHPI Daemon Restart 12-18
The Netra Data Plane Suite 12-19
..... 12-20
Objectives 13-1
Additional Resources 13-2
Introduction To The Sun NetraTM CP3x40 Switch 13-3
NetraTM CP3140 1GB Switch 13-4
NetraTM CP3240 10GB Switch 13-5
Supported Configurations Of The Sun NetraTM CP3x40 Switch 13-6
Sun NetraTM CP3x40 Switch Hardware Components 13-7
Pairing Switches and RTMs 13-7
Switch Redundancy 13-8
The FASTPATH Software 13-9
Supported Switching Protocols 13-11
Base Network Connections 13-12
Extended Network Connections 13-13
FASTPATH Stacking Capabilities 13-14
FASTPATH Switching 13-14
Additional Layer 2 Functionality 13-15
System Facilities 13-16
Switching MIBs 13-17
FASTPATH Routing 13-17
Routing MIBs 13-18
FASTPATH Quality of Service (DiffServ) 13-18
Access Control Lists (ACLs) 13-20
Class of Service (CoS) 13-20
Quality of Service MIBs 13-21
FASTPATH Multicast 13-21
Multicast MIBs 13-21
FASTPATH BGP-4 13-22
BGP-4 MIBs 13-22
FASTPATH IPv6 Routing 13-22
IPv6 Routing MIBs 13-23
FASTPATH Management 13-23
SSL 3.0 and TLS 1.0 13-24
SSH 1.5 and 2.0 13-24

Copyright 2009 Sun Microsystems, Inc. All Rights Reserved. Sun Services, Revision A

Objectives 14-1
Additional Resources 14-2
Overview of NetraTM CT900 Architecture 14-3
NetraTM CT900 Hardware Architecture 14-3
Netra CT900 Components 14-4
CP3240 Components 14-11
Netra CP32x0 Advanced Rear Transition Modules 14-13
Netra ATCA System Management 14-18
Shelf Management Module (ShMM) 14-19
Power Entry Modules 14-19
uBoot Overview 14-20
uBoot Console 14-20
E-Keying 14-23
Disabling Board E-Keying 14-23
Re-Enabling E-Keying 14-24
Objectives 15-1
Additional Resources 15-2
Installation Requirements 15-3
Software Components 15-3
The FASTPATH Software 15-3
Configure the NetraTM CP3x40 Switch Jumpers 15-5
Additional Jumper Settings 15-6
Removing and Installing Switches 15-7
Removing a Switch Set 15-7
Removing a Rear Transition Module for a Switch 15-8
Installing a Switch Set 15-9
NetraTM CP3x40 Switch Unit Firmware Upgrades 15-11
Physical Setup for a Switch Unit Firmware Update 15-12
Updating From the Switch Unit OS 15-12
Updating From the Boot Utility Menu 15-15
Recovering from Corrupted Firmware or a Failed Firmware Update 15-19
IPMC Update Failure 15-20
Accessing The Sun NetraTM CP3x40 Switch Console 15-21
Serial Port Console Access 15-21
Network Connection 15-22
Enable Mode 15-23
Switch Logout 15-23
Changing the Command Line Prompt 15-23
Exercise: Setting Up The Sun NetraTM CP3x40 Switch 15-24
Objectives 16-1
Additional Resources 16-2
Understand FASTPATH Command Syntax Rules 16-3
Command Conventions 16-3
Parameter Conventions 16-3
Values of Common Parameters 16-4

Copyright 2009 Sun Microsystems, Inc. All Rights Reserved. Sun Services, Revision A

Command Completion 16-6
Accessing The Switch 16-7
Using The Switch Configuration Commands 16-8
? command 16-8
show ? command 16-9
show users command 16-11
show loginsession command 16-11
show serial command 16-12
show hardware command 16-12
show sysinfo command 16-14
hostname command 16-15
Setting Port Configurations 16-16
Management Network Interface Configuration 16-16
show serviceport command 16-16
serviceport protocol command 16-17
serviceport ip command 16-17
Shelf Network Interface Configuration 16-18
show network command 16-18
network parm command 16-20
Testing the Configuration Using ping 16-20
CP3240 Logical Switch Ports 16-21
show port all command 16-27
Configuring Spanning Tree Protocol (STP) 16-29
spanning-tree command 16-29
show spanning-tree summary command 16-30
show spanning-tree brief command 16-31
show spanning-tree command 16-32
no spanning tree command 16-33
Additional Spanning Tree Commands 16-34
Administering Virtual LANs (VLAN) 16-38
show vlan command 16-38
vlan database command 16-39
network mgmt_vlan command 16-39
vlan port tagging all command 16-39
To Configure a VLAN 16-39
Advanced Switching Commands 16-43
Managing The Switch Configuration 16-46
Displaying the Current Configuration 16-46
Saving the Active Configuration 16-51
Saving and Restoring a Switch Unit's Configuration 16-52
Resetting a Lost Switch Unit Password 16-55
Resetting The Switch Configuration Defaults 16-57
VLAN 55 16-58
Exercise: Configuring the Switch 16-60
Task 1 – Connect into the switch 16-60
Task 2 – Connect into the blades 16-61

Copyright 2009 Sun Microsystems, Inc. All Rights Reserved. Sun Services, Revision A

Task 3 – Configure the VLAN 16-61
Task 4– Configure the switch to support STP 16-62
In this task, you will configure your blades and switch to support the Spanning Tree Protocol (STP). 16-62
Objectives 17-1
Additional Resources 17-2
FASTPATH IP Routing Commands 17-3
Understanding Port Routing 17-3
show ip brief command 17-4
show ip interface command 17-4
show ip interface brief command 17-6
show ip route command 17-6
routing command 17-7
no routing command 17-7
no ip routing command 17-7
ip address command 17-8
no ip address command 17-8
ip route command 17-8
no ip route command 17-9
ip route default command 17-9
no ip route default command 17-9
ip route distance command 17-9
no ip route distance command 17-10
ip forwarding command 17-10
no ip forwarding command 17-10
ip netdirbcast command 17-11
no ip netdirbcast command 17-11
ip mtu command 17-11
no ip mtu command 17-11
encapsulation command 17-12
FASTPATH DHCP And BOOTP Commands 17-13
show bootpdhcprelay command 17-13
bootpdhcprelay cidoptmode command 17-14
no bootpdhcprelay cidoptmode command 17-14
bootpdhcprelay enable command 17-14
no bootpdhcprelay enable command 17-14
bootpdhcprelay maxhopcount command 17-14
no bootpdhcprelay maxhopcount command 17-14
no bootpdhcprelay minwaittime command 17-14
no bootpdhcprelay minwaittime command 17-15
bootpdhcprelay serverip command 17-15
bootpdhcprelay serverip command 17-16
FASTPATH Address Resolution Protocol (ARP) Commands 17-17
arp command 17-17
no arp command 17-17
show arp command 17-17

Copyright 2009 Sun Microsystems, Inc. All Rights Reserved. Sun Services, Revision A

show arp brief command 17-18
show arp switch command 17-19
ip proxy-arp command 17-19
no ip proxy-arp command 17-19
arp cachesize command 17-20
no arp cachesize command 17-20
arp dynamicrenew command 17-20
no arp dynamicrenew command 17-20
arp purge command 17-20
arp resptime command 17-20
no arp resptime command 17-21
arp retries command 17-21
no arp retries command 17-21
arp timeout command 17-21
no arp timeout command 17-21
clear arp-cache command 17-21
Advanced FASTPATH Routing Commands 17-22
Exercise: Configuring the Switch Routing 17-23
Task 1 – Configure routing on the switch 17-23
Task 2 – Enabling Routing for Ports on the Switch 17-24
Task 3 – Verify the Routing Configuration 17-25
Task 4– Remove routing support 17-25
In this task, you will remove the routing configuration you just made. 17-25
Objectives 18-1
Additional Resources 18-2
Configuring IPV6 Networks 18-3
The Need for IPv6 18-3
Features of IPv6 18-4
Introducing IPv6 Addressing 18-5
Address Types 18-5
IPv6 Address Representation 18-6
Format Prefixes 18-6
FASTPATH IPv6 Commands 18-7
FASTPATH IPv6 Commands 18-8
show ipv6 command 18-8
ipv6 enable command 18-8
no ipv6 enable command 18-9
ipv6 forwarding command 18-9
no ipv6 forwarding command 18-10
ipv6 unicast-routing command 18-10
no ipv6 unicast-routing command 18-10
Creating IPV4 to IPV6 Tunnels 18-11
show interface tunnel command 18-11
Using Advanced FASTPATH IPV6 Commands 18-12
Configuring Multicast Settings 18-17

Copyright 2009 Sun Microsystems, Inc. All Rights Reserved. Sun Services, Revision A

ip multicast command 18-17
..... 18-19
Multicast Example 18-19
Reviewing Multicast Statistics 18-21
show ip igmp interface stats command 18-21
..... 18-21
Objectives 19-1
Additional Resources 19-2
Class of Service (CoS) 19-3
IPQoS Terminology 19-3
Solaris™ OS IPQoS Implementation 19-4
The QoS Policy 19-5
IPQoS Module 19-5
Support for 802.1D User Priority Mapping 19-7
FASTPATH CoS Commands 19-7
classofservice dot1p-mapping command 19-8
no classofservice dot1p-mapping command 19-8
classofservice ip-precedence-mapping command 19-8
no classofservice ip-precedencemapping command 19-8
classofservice ip-dscp-mapping command 19-8
no classofservice ip-dscp-mapping command 19-8
QoS Differentiated Services (DiffServ) 19-9
Enabling DiffServ Inbound 19-11
Configuring the IPQoS Facility In Solaris 10 19-13
Advanced Quality of Service Commands 19-14
Objectives 20-1
Additional Resources 20-2
Overview 20-3
show tech-support command 20-4
Exercise: Configuring the Switch 20-6
Task 1 – Connect into the switch 20-6
Task 2 – Connect into the blades 20-7
Task 3 – Configure the swith to support a VLAN 20-7
Objectives A-1
Older Sun Netra Blade Systems A-2
Preparing a Solaris TFTP Server A-3
Preparing the Directory A-3
Solaris 9 ..... A-3
Solaris 10 ..... A-5
Preparing a Linux TFTP Server A-6
TFTP with IPTables A-6
Board Batteries A-7
PMC and CMC Cards A-9
The PMC – PCI Mezzanine Card A-9
The CMC – Common Mezzanine Card A-11
Serial Port Connections A-12

Copyright 2009 Sun Microsystems, Inc. All Rights Reserved. Sun Services, Revision A

Cable Types and Signals A-12
Cable Lengths A-13
Host Serial Device Names A-13
The `tip` Command A-14
`tip` Environment Variables A-15
`tip` Lock File A-15
The `.tiprc` File A-16
The `/etc/remote` File A-16
Example A-18
The `minicom` command. A-19
`minicom` keyboard short cut keys A-22
Configure serial port using `minicom` A-23
The Cluster Console A-24
Installing the Cluster Console A-26
Telecom Clocking A-28
Clock Sources A-28
Clock Signal Types A-29
Bit Conversions A-30
Standard Connector Structure A-31
RJ-45 ..... A-31
DB-9 ..... A-32
SAP Connector Pinouts A-33
SAP Serial Ports Pinout A-33
SAP Telco Alarm Port Pinout A-34
Use of the Telco Alarm Port A-35
Alarm Presence A-35
Alarm Reset A-35
CP3140 Switch Connector Pinouts A-36
CP3140 Switch Ethernet Connector Pinout A-36
CP3140 Switch Serial Port Pinout A-37
Node Blade Serial Console Pinout A-38
CP3010/CP3020 RTM Connector Pinouts A-39
CP3010/CP3020 RTM Ethernet Connector Pinout A-39
CP3010/CP3020 RTM Serial Port Pinout A-40
USB Connector Pinout A-41
External SAS Connector Pinout A-42

Copyright 2009 Sun Microsystems, Inc. All Rights Reserved. Sun Services, Revision A